Philips
Remote control

RC4718

To operate your device from a distance

Check compatibility data

For fast and easy control of your device. Is your old remote control lost or broken? Order a new one here! Delivered without batteries.

Ease of using Philips spare parts

- Renew your product with original Philips parts

PHILIPS
sense and simplicity

Specifications

Replaceable part

- Fits product types:: 14PT2666/01, 14PT2666/05, 14PT2666/05R, 14PT2666/58, 15PT2966/01, 15PT2967/01B, 15PT2967/01S, 15PT2967/58B, 15PT2967/58S, 21PT4406/01, 21PT4406/58, 21PT4416/01, 21PT4416/05, 21PT4420/01, 21PT4420/05, 21PT4426/01, 21PT4426/58, 21PT4438/01, 21PT4457/01, 21PT4457/05, 21PT4457/58, 21PT4458/01, 21PT4458/05, 21PT4458/58, 21PT5306/01, 21PT5401/01, 21PT5401/05, 21PT5401/58, 21PT5407/01, 21PT5407/05, 21PT5407/58, 21PT5408/01, 21PT5408/58S, 21PT5409/01, 21PT5409/05, 21PT5420/01, 21PT5457/01, 21PT5457/05, 21PT5457/58, 21PT5458/01, 21PT5507/01, 21PT5507/05, 21PT5507/58, 21PT5509/01, 21PT5518/01, 21PT5518/05, 21PT5518/58, 21PT5520/01, 21PT5520/05, 21PT5520/58, 21PT5606/01, 21PT5606/58, 24PW6006/01, 24PW6006/05, 24PW6407/01, 24PW6407/05, 24PW6518/01, 24PW6518/05, 25PT4107/58, 25PT4426/01, 25PT4457/01, 25PT4457/05, 25PT4457/21, 25PT4457/58, 25PT4458/01, 25PT4458/05, 25PT5007/01, 25PT5007/58, 25PT5107/01, 25PT5107/58, 28PT4406/01, 28PT4406/58, 28PT4408/01, 28PT4418/01, 28PT4418/05, 28PT4426/01, 28PT4438/01, 28PT4457/01, 28PT4457/05, 28PT4457/58, 28PT4458/01, 28PT4458/05, 28PT4557/01, 28PT4657/01, 28PT5007/01, 28PT5007/58, 28PT5008/01, 28PT5107/01, 28PT5107/58, 28PW5407/01, 28PW5407/05, 28PW5408/01, 28PW6006/01, 28PW6006/05, 28PW6006/21, 28PW6006/25, 28PW6006/48, 28PW6006/58, 28PW6008/01, 28PW6008/05, 28PW6008/58, 28PW6106/05, 28PW6108/01, 28PW6206/01, 28PW6306/01, 28PW6408/01, 28PW6408/05, 28PW6420/01, 28PW6420/05, 28PW6506/01, 28PW6506/05, 28PW6506/58, 28PW6517/01, 28PW6517/05, 28PW6518/01, 28PW6518/05, 28PW6518/58, 28PW6520/01, 28PW6520/05, 29PT5306/01, 29PT5306/01E, 29PT5407/01, 29PT5407/21, 29PT5408/01, 29PT5458/01, 29PT5460/01, 29PT5506/01, 29PT5506/01E, 29PT5506/58, 29PT5507/01, 29PT5507/21, 29PT5507/58, 29PT5509/01, 29PT5518/01, 29PT5520/01, 29PT5520/58, 29PT5606/01, 29PT5606/58, 32PW5407/01, 32PW5407/05, 32PW5407/21, 32PW5407/25, 32PW6006/01, 32PW6006/05, 32PW6006/21, 32PW6006/25, 32PW6006/48, 32PW6006/58, 32PW6408/01, 32PW6408/05, 32PW6420/01, 32PW6420/05, 32PW6506/01, 32PW6506/05, 32PW6506/58, 32PW6517/01, 32PW6517/05, 32PW6518/01, 32PW6518/05, 32PW6518/58, 32PW6520/01, 32PW6520/05, 72TA5216/03, 72TA5216/11
- Fits product type:: 29PT5507/94

Highlights

Easy replacement

From time to time your product needs a facelift, and with Philips consumer replacement parts to renew your product, it's never been so easy! All this with guaranteed Philips quality and 1:1 exchange.

Issue date 2012-02-15

Version: 2.0.1

© 2012 Koninklijke Philips Electronics N.V.
All Rights reserved.

Specifications are subject to change without notice. Trademarks are the property of Koninklijke Philips Electronics N.V. or their respective owners.

www.philips.com